

Notes:

1. ALL INTERCONNECTING PIPE AND FITTINGS SHALL BE INSTALLED BY THE CONTRACTOR.
2. PIPING LAYOUT IS DIAGRAMMATIC ONLY. FINAL ARRANGEMENT WILL BE SITE SPECIFIC. CONTRACTOR WILL BE RESPONSIBLE FOR FIELD VERIFICATION AND COORDINATING ACTUAL LOCATION WITH ALL OTHER TRADES.
3. CONTRACTOR SHALL VERIFY MOTOR VOLTAGE, PHASE, AND AMP RATINGS BEFORE STARTING ELECTRICAL INSTALLATION; AND MAKE CERTAIN THE VOLTAGE SUPPLIED BY THE FACILITY IS THE SAME.
4. THE ROOM REQUIRES DEDICATED MECHANICAL VENTILATION WITH AN ALLOWABLE TEMPERATURE VARIANCE OF 40° TO 105°. (FOR HIGHER AMBIENTS, CONSULT FACTORY).
5. ALLOW 36 INCHES IN FRONT OF CONTROL PANEL FOR MAINTENANCE AND VENTILATION, ALL OTHER SIDES REQUIRE 24 INCHES OF CLEARANCE.
6. ALL ACCESSORIES, PIPE, AND FITTINGS BEYOND DISCHARGE PORTS ARE SUPPLIED AND INSTALLED BY OTHERS.

-FOR DISCHARGE PIPE SIZING REFER TO STANDARD PRESSURE DROP TABLES.
-TOTAL PRESSURE DROP SHOULD BE LESS THAN 5 PSIG.

TO FACILITY

SOURCE VALVE
BY OTHERS

ETHERNET WIRING ACCESS
ALARM WIRING ACCESS

SINGLE POINT POWER
WIRING ACCESS

NOTE:
ALL ACCESSORIES, PIPE, AND
FITTINGS BEYOND INLET AND
DISCHARGE PORTS ARE SUPPLIED
AND INSTALLED BY OTHERS.

DISCHARGE CONNECTION

SINGLE POINT DRAIN
CONNECTION, CONTRACTOR
SHALL PIPE TO FLOOR DRAIN.

NO VIBRATION PADS ARE
NECESSARY AT THIS LOCATION

NO FOUNDATION OR INERTIA PAD IS REQUIRED
(HOUSEKEEPING PAD IS OPTIONAL)

HEAVY-DUTY
4-POINT ISOLATION
(SEISMIC OPTIONAL)

Revised: MDB	Date: 07/01/2019	Drawn: JDY	Date: 01/27/2011
BEACONMEDA'S		This drawing and the information contained therein remain the property of BeaconMedaes and may not be used for other than the purpose for which it is loaned without the expressed written permission from BeaconMedaes Engineering.	
Description: INST DIA - LAB AIR PX SCROLL SPC 10-15HP 10 BAR W/ DESC DRYER		Part Number: 4107 8526 43	
DN: BM190343		Rev: 02	
Sheet 1 of 1		DO NOT SCALE THIS DOCUMENT	